

Supplemental Mounting Kit for Kenworth and the Western Star Trucks with composite wood fiber and plastic technology floor construction.

01-20-2001

The mounting kit is compatible with the following products:

- **Air Top 2000 Sleeper Kit P/N 920520**
- **Air Top 3500 Arctic Heater Kit P/N 920544**
- **Tandem Heater Kit P/N 923058**

The mounting kit includes all necessary hardware* and instructions for preparing the composite floor of the Kenworth and Western Star trucks for installation of the Air Top 2000, Air Top 3500 Sleeper Kits and the Tandem Kit.

*Supplemental mounting kit does not include required epoxy adhesive.

To prevent damage to the composite floor material used in the construction of the Kenworth and Western Star trucks, it is vitally important that the mounting site be prepared using the supplemental mounting kit. Failure to do so may result in future damage and weakening of the floor around the area of the heater. Should the sealing around the base of the heater be damaged or compromised as a result, hazardous fumes may enter the sleeper area!



Ordering Information

The mounting kit is available from Webasto, Kenworth and Western Star truck dealers under part number 906324.