

Webasto Inbuilt Sunroof Water Management System

The Webasto water management system is designed to disperse water through drain tubes to the exterior of the vehicle. The system prevents water entry into the vehicle interior according to standards listed below.

Glass Panel in closed position:

- Opening a wet panel to tilt position after a rainfall.
- Rainfall on the glass panel.
- Automatic car-wash (with brushes) treatment.
- Manual vehicle wash with hose at 87 PSI for 5 minutes at a distance of 3 feet (maximum water flow 10.5 gal / minute).
- Nozzle pointed directly at the Seal (87 PSI, 10.5 gal/m max water flow) for 5 seconds.
- Manual vehicle wash with high-pressure spray-gun 435 PSI, for 5 minutes at a distance of 1.5 feet (3.4 gal/m max water flow).
- Nozzle pointed directly at the Seal (435 PSI, 3.4 gal/m max water flow)

Water Management System Maintenance

In order to maintain the functionality of the water management system it is necessary to keep it free of dirt and debris. Webasto recommends to clear the drain tubes of anything that may be inhibiting full drainage capacity a minimum of once per year.

NOTE: It is normal to feel / see water in the drain trough from the vehicle interior.